

After the Blasting Process

SODA BLASTER SALES

Blasting Exterior Only:

Please note that we will tape off about a 1” seam around all openings. This ensures soda does not buildup in unwanted areas, and your painter will be able to “feather” the new paint job.

After Blasting:

Paint/Primer will not stick to soda. The car MUST be washed thoroughly before preparing the surface for paint. Hot water, Dawn ® Dish Soap and water are both acceptable methods. A garden hose and sponge wash is better than a pressure washer.

This should be done as close to the time of paint as possible to ensure a great finish.

A Self Etching Primer is the next step after washing.

